





General Notes:

- 1. SDS = self-drilling tapping screw
- 2. Screw end distance and edge distance is 9/32" minimum. Screw spacing is 9/16" minimum.
- The top and bottom chords of all trusses shall be properly connected to structural sheathing or purlins, designed by others.
- 4. R_V refers to vertical reaction, and U refers to uplift.
- 5. Clip fastener placement is identical on opposite side to what is shown.
- 6. When supported truss has a Z-Web vertical refer to TS068 for connection areas.
- 7. Cold—Formed Steel calculations are per the 2010 supplement to the AISI 2007 "North American Specification for the Design of Cold—Formed Steel Structural Members" (\$100-07/\$2-10).

TrusSteel®

 $R_{V} = U = 3000 \#$

www.TrusSteel.com

Florida: 2400 Lake Orange Drive, Suite 150 / Orlando, FL 32837 / (800) 755-6001 Missouri: 13389 Lakefront Drive / Earth City, MO 63045 / (800) 326-4102

90° Truss -to-Truss Connection

ITW Building Components Group, Inc. shall not be responsible for any performance failure in a connection due to a deviation from this detail. Any variation from this detail shall be approved in advance by ITW Building Components Group, Inc. Custom Detall: CD130904 Date:

09/25/13

Custom Detail Category:

Truss-to-Truss Connection