



## Partial Roof Layout

## General Notes:

1. SDS = self-drilling tapping screw.

- 2. Screw spacing, edge distance and end distance is 9/16" (14mm) minimum for #10SDS and 3/4" (19mm) minimum for #14AMDB1.25 fasteners.
- 3. Hip ridge blocking designed to support vertical load only (from gravity load and wind load). If blocking needs to support any other type of load, contact a TrusSteel engineer.
- 4. This detail may be used for roof pitches from 2.2/12 (10°) to 12/12 (45°).
- Equal screws must be placed in flat areas for Z-webs. Refer to TS011A and TS068 for fastener contact areas.
- Cold—Formed Steel Calculations are per the 2010 supplement to the AISI 2007 "North American Specifications for the Design of Cold—Formed Steel Structural Members" (\$100-07/\$2-10).

## TrusSteel®

www.TrusSteel.com

Florida: 1950 Marley Drive / Haines City, FL 33844 / (800) 755-6001 Missouri: 13389 Lakefront Drive / Earth City, MO 63045 / (800) 326-4102 Hip Ridge Blocking Framing Detail For 48" (1219mm) O.C. Trusses

ITW Building Components Group, Inc. shall not be responsible for any performance failure in a connection due to a deviation from this detail. Any variation from this detail shall be approved in advance by ITW Building Components Group, Inc.

Standard Detail: TS056A Date:

07/16/12

TrusSteel Detail Category:

Hip Framing